

Aquapure™ Aquapucks

DESCRIPTION

Aquapure™ Aquapucks are easy to use puck-sized tablets, used to reduce odors caused by anaerobic conditions and F.O.G. build up in wastewater. These tablets combine oxygenating technology with bio-degradable bacteria to eliminate noxious odors. Aquapure™ Aquapucks also break down fats, oils and greases from the most difficult grease traps. The action generated from Aquapure™ Aquapucks purges odors and gases from water and prevents them from reforming.

FEATURES AND BENEFITS

- Easy to use puck shaped tablet
- One step use
- Reduces ODOR, BOD and TSS
- Environmentally friendly
- Biodegradable-sustainable
- Can be used as pretreatment or as an aid during treatment

TYPICAL APPLICATIONS

- Use to reduce wastewater odors due to anaerobic conditions (sulfur compounds, fatty acids and nitrogen compounds)
- Wastewater lift stations
- Equalization Tanks and Basins
- Pretreatment for odorous waste in transport
- To augment secondary aeration and clarification processes
- Prevents acid degradation to concrete infrastructure, pipes and fittings



Aquapure™ Aquapucks

Product Code: 2601086
Revised Date: March 19, 2015

DOSAGE AND USE SUGGESTIONS

- Odor inhibition translates to 1.7 lbs of pucks per lb of sulfide for reduction in wastewater per day.
- Apply product closest to waste generation to maximize contact time
- Pucks dissolve in 4 to 8 hours depending upon temperature and flow
- Pucks must be submerged at lowest point in waste stream and beneath grease cap if present.

CAUTION

Use only as directed. Use proper hand and eye protection during application. Wash hand after use with warm, soapy water.

AVAILABILITY

Aquapure™ Aquapucks are available in 30 pound pails – packaged in 1 lb sleeves (3 pucks / lb)

WARRANTY

THE QUALITY OF THIS PRODUCT IS GUARANTEED ON SHIPMENT FROM OUR PLANT. IF THE USE RECOMMENDATIONS ARE FOLLOWED, DESIRED RESULTS WILL BE OBTAINED. SINCE THE USE OF OUR PRODUCTS IS BEYOND OUR CONTROL, NO GUARANTEE EXPRESSED OR IMPLIED IS MADE AS TO THE EFFECTS OF SUCH USE, OR THE RESULTS TO BE OBTAINED.